# Painting near mobile powered plant



High Risk Construction Work Activity:	At workplaces where there is any movement of powered mobile plant
What:	Painting an exterior wall using a powered elevated work platform
Where:	Outside of a building
Who:	Typically involving 2 or more painters

### 1. ELIMINATION

 Close work areas to all powered mobile plant

#### 2. MODIFICATION

- Barricaded from other machinery and objects with boom reach.
- Separate painters from areas where powered plant operate, with the use of barriers
- Fit beepers / alarms to all powered mobile plant
- Remove all painting staff from areas where there is the movement of powered mobile plant

## 3. ADMINISTRATION

- Follows directions as determined in the traffic management plan
- Follow SWMS of Principle Contractor in regards to the work in the areas where powered mobile plant operate
- Consult with the building contractor, safety officer and / or HSR regarding any specific actions required when working in these areas.
- Use signal persons to restrict / manage powered mobile plant operations during painting operations
- Cease painting operations during periods of operation of powered mobile plant
- Use a spotter
  - Use trained and experienced staff to undertake activities where powered mo-

# 4. PERSONAL PROTECTION

Hig<mark>h visibility w</mark>ork wear